The Reflection Coefficient

So, we know that the transmission line voltage V(z) and the transmission line current I(z) can be related by the line impedance Z(z):

$$V(z) = Z(z) I(z)$$

or equivalently:

 $I(z) = \frac{V(z)}{Z(z)}$

Expressing the "activity" on a transmission line in terms of voltage, current and impedance is of course **perfectly** valid. However, let us look **closer** at the expression for each of these quantities:

$$V(z) = V^+(z) + V^-(z)$$

$$I(z) = \frac{V^{+}(z) - V^{-}(z)}{Z_{0}}$$

$$T(z) = Z_0 \left(\frac{V^+(z) + V^-(z)}{V^+(z) - V^-(z)} \right)$$

Z

It is evident that we can **alternatively** express all "activity" on the transmission line in terms of the two transmission line **waves** $V^+(z)$ and $V^-(z)$.

In other words, we can describe transmission line activity in terms of:

$$V^{\scriptscriptstyle +}(z)$$
 and $V^{\scriptscriptstyle -}(z)$

instead of:

$$V(z)$$
 and $I(z)$

Q: But V(z) and I(z) are related by line impedance Z(z):

$$Z(z) = \frac{V(z)}{I(z)}$$

How are $V^+(z)$ and $V^-(z)$ related?

A: Similar to line impedance, we can define a new parameter the **reflection coefficient** $\Gamma(z)$ --as the **ratio** of the two quantities:

$$\Gamma(\boldsymbol{z}) \doteq \frac{\boldsymbol{V}^{-}(\boldsymbol{z})}{\boldsymbol{V}^{+}(\boldsymbol{z})}$$

More specifically, we can express $\Gamma(z)$ as:

$$\Gamma(z) = \frac{V_0^- e^{+\gamma z}}{V_0^+ e^{-\gamma z}} = \frac{V_0^-}{V_0^+} e^{+2\gamma z}$$

Note then, the value of the reflection coefficient at z=0 is:

$$\Gamma(z = 0) = \frac{V_0^{-}}{V_0^{+}} e^{+2\gamma(0)}$$
$$= \frac{V_0^{-}}{V_0^{+}}$$

We define this value as Γ_0 , where:

$$\Gamma_{0} \doteq \Gamma(z=0) = \frac{V_{0}^{-}}{V_{0}^{+}}$$

Note then that we can alternatively write $\Gamma(z)$ as:

$$\Gamma(\boldsymbol{Z}) = \Gamma_0 \boldsymbol{e}^{+2\gamma \boldsymbol{Z}}$$



Look what happened—the line impedance can be completely and explicitly expressed in terms of reflection coefficient $\Gamma(z)$!

Or, rearranging, we find that the reflection coefficient $\Gamma(z)$ can likewise be written in terms of line impedance:

$$\Gamma(\boldsymbol{z}) = \frac{Z(\boldsymbol{z}) - Z_0}{Z(\boldsymbol{z}) + Z_0}$$

Thus, the values $\Gamma(z)$ and Z(z) are **equivalent** parameters if we know **one**, then we can determine the **other**!

Likewise, the relationships:

$$V(z) = Z(z) I(z)$$

and:

$$\mathcal{V}^{-}(\boldsymbol{z}) = \Gamma(\boldsymbol{z}) \mathcal{V}^{+}(\boldsymbol{z})$$

are equivalent relationships—we can use either when describing an transmission line.

> Based on circuits experience, you might be **tempted** to always use the **first** relationship. However, we will find that it is also **very** useful (as well as simple) to describe activity on a transmission line in terms of the **second** relationship—in terms of the **two** propagating transmission line **waves**!